

Quick Reference Card in.xm



in.k400


Series of compact full-function keypads for in.xm spa systems


Aeware's new series of keypads features a large LCD display and raised keys that let users control all in.xm functions and programming directly from spa side. In.k400 comes in an easy to install waterproof plastic enclosure and is designed to maximize user experience.













On/Off key (1)

Depending on the spa manufacturer, this key may have different functions: On/Off, Standby mode or quick enable of the Economy mode.

Standby Mode: Use On/Off key to pause all pumps* Progress bar will display the remaining time before the system automatically exits Standby mode (user can also exit Standby mode at any time by pressing again on On/Off key).

In order to warn the user, the spa light will flash for a few seconds before the exit of Standby mode and restart the pumps. The "Stby" message is also displayed during Standby mode.

* Pump will stay turned on if there is a request for more

Pump1key 1

Press Pump 1 key to turn Pump 1 on at low speed. Press a second time to turn pump to high speed (with a dual-speed pump). A third time turns pump off.

A built-in timer automatically turns pump off after 20 minutes, unless pump has been manually deactivated first.

Pump 2 key 2

Press Pump 2 key to turn Pump 2 on at low speed. Press a second time to turn pump to high speed (with a dual-speed pump). A third time turns pump off.

A built-in timer automatically turns pump off after 20 minutes, unless pump has been manually deactivated first.

Pump 3 key 3

Press Pump 3 key to turn Pump 3 on. Press a second time to turn pump off.

A built-in timer automatically turns pump off after 20 minutes, unless pump has been manually deactivated first.

Note: option available in certain models only.

Light key


Press Light key to turn light on at high intensity. Subsequent presses change light intensity. A last press turns light off.

A built-in timer automatically turns light off after 2 hours, unless it has been manually deactivated first.

Programming Steps










Press Pump key again to turn pump off.

* If single speed pump: press Pump key to turn pump on.







Up/Down keys ▲ ▼

Use Up or Down key to set desired water temperature. The temperature setting will be displayed for 5 seconds to confirm your new selection.

The "Set Point" icon indicates that the display shows the desired temperature, NOT the current water temperature!

Program key 😉 Setting the time

Use **Program** key to display Enter Programming mode time or enter Programming by holding Prog. key pressed menu by pressing and down for 3 sec. The display holding key. In Programming mode, the following will show the current time setting. parameters can be set: time, filter cycle start time, filter Setting the hour: Use Up or

Down arrows to change hour setting (AM/PM).

Setting the minutes: Press Prog. key a second time.

Use Up or Down key to change hour setting.

Setting filter cycle start time

To program the filter cycle, you must enter these parameters: the start time, duration and frequency. During a filter cycle, pumps run for one minute to purge the plumbing, then Pump 1 runs for the programmed number of hours. Press Prog. key a third time. The display will show **FSxx**, with "xx" representing the starting hour. Use Up or

Down key to change setting.

Setting filter cycle duration

Press Prog. key a fourth time. The display will show Fdxx, with "xx" representing the duration in hours.

Use Up or Down key to change setting.

Filter cycle frequency

Press **Prog**. key a fifth time. The display will show **FFxx**, with "xx" representing the number of filter cycles per day (up to 4).

Use Up or Down key to change setting.



Setting economy mode

This mode allows you to lower the temperature set point of the spa by 20 °F (11 °C) during a certain period

Press Prog. key a sixth time. Use Up key to enable the economy mode, the display will show EP1 or use Down key to disable economy mode, the display will show



cycle duration, filter cycle

Note: Light key is used as

present.

Program key if this key is not

frequency, and temperature

Setting economy start time

Press Prog. key an seventh time. The display will show ESxx, with "xx" representing the starting hour.


Use Up or Down key to change setting.



Setting economy end time

Press Prog. key a eighth time. The display will show EExx, with "xx" representing the ending time in hour.

Use Up or Down key to change setting.



Setting temperature unit

Water temperature can be displayed in either Fahrenheit (°F) or Celsius (°C). Press **Prog**. key a ninth time. The display will show either °F or °C.

Use Up or Down key to change setting.

Press Prog. key once more to go back to normal mode.



Smart Winter Mode

Our Smart Winter Mode protects your system from the cold by turning pumps on several times a day to prevent water from freezing in pipes.



Water temperature regulation

In a regulation cycle, the system first generates water flow through the heater housing and the plumbing, in order to ensure accurate water temperature readings as well as avoiding heater activation in dry conditions.

After verifying pump activation and taking a water temperature reading if required, the system automatically turns the heater on to reach and maintain water temperature at Set Point.

Cooldown

After heating the spa water to the desired Set Point, the heater is turned off, but its associated pump (Pump 1 Low-speed or CP) remains on for a predetermined period of time to ensure adequate cooling of the heating element, this prolongs its useful life. The heater icon flashes



